

# METRACELL BT PRO

## Portable Battery Tester

3-447-057-03  
3/12.22

- Measurement of block voltages
- Measurement of overall voltages up to 600 V<sub>DC</sub> and 300 V<sub>AC</sub>
- Capacity tests of individual blocks and entire batteries
- Internal resistance measurement with simultaneous measurement of the electric resistance ( $R_{el}$ )<sup>1</sup> and electrochemical (charge-transfer) resistance ( $R_{ct}$ )<sup>2</sup> for the determination of the battery status with the highest possible degree of accuracy
- Measurement of voltage drops at connectors
- Automated recording of voltage and current curves (current curves with optional sensor technology)
- Measurement of block temperatures (with optional sensor technology)
- Import of density values by directly connecting a DMA 35 density sensor from Anton Paar GmbH
- Mobile and safe usage in the field thanks to convenient carrying options and rugged design
- Battery identification by means of RFID tag reader
- Storage of up to 300,000 data records
- Multilingual battery tester management software for the management of battery databases and measurement data as well as for the analysis of measurement data including the generation of meaningful reports
- Wireless transmission of measurement data



## Applications

Periodic testing and well-organized maintenance are necessary in order to assure the availability of stationary battery systems. The METRACELL BT PRO is a universal, multifunctional test instrument for user-friendly, professional maintenance of these battery systems. It can be used to determine the current status of the battery or battery block and pinpoint hidden battery defects. The battery tester is used primarily for testing stationary battery systems.



Figure 1: Carrying case (left), analysis of measurement data (right)

## Features

- Simple and intuitive menu structure
- Easy-to-understand display of measured values
- Illuminated high-contrast display
- Compact design and shockproof ABS housing with additional rubber holster
- Unrestricted motion thanks to carrying strap, fastening clip and magnet
- Automatic measured value acquisition with acoustic feedback
- Integrated wireless interface
- Integrated infrared interface
- Operating time approx. 10 hours
- Battery operation, equipped with 4 NiMH rechargeable batteries and battery charger as standard equipment
- Kelvin probes for 4-wire measurement (suppress influence of cable and contact resistances on the resistance measurement results)
- Carrying case for the safe storage of test instrument and accessories
- PC-aided management, evaluation and storage of measured values

1) Electrical Resistance  $R_{el}$

is a measure of strictly electrical losses. These losses occur at, for example, plate straps, plate grids and electrolytes. The battery delivers rapidly changing currents via this resistance, for example for switched-mode DC/DC converters. Together with  $R_{ct}$ , it adds up to the  $R_{DC}$  (direct current resistance) of a battery.

2) Charge Transfer Resistance  $R_{ct}$

Characterizes the ability of a block to accumulate and release a charge. This makes it possible to identify battery blocks (with electro-chemical defects) which are operating at a loss during float. Together with  $R_{el}$ , it adds up to the  $R_{DC}$  (direct current resistance) of a battery.


# METRACELL BT PRO

## Portable Battery Tester

### Measurements

Measurement	Description
MULTIMETER	DC and AC voltage measurements without storing measured values.
FLOAT	Periodic measurement of block voltages. This measurement is used for the frequent recording of the float voltage level of battery blocks, for example in UPS systems.
DISCHARGE	Multiple measurement of block voltages at short intervals during a discharge cycle (capacity tests of blocks).
CHARGE	Multiple measurement of block voltages at short intervals during a charge cycle (capacity tests of blocks).
RESISTANCE	Periodic measurement of the internal resistance of the blocks
TEMPERATURE	Measurement of block temperature with an IR temperature sensor
CONNECTOR	Measurement of voltage drop to determine connector loss between blocks
INTERVAL U	Measurement of the voltage of a battery at any desired time interval (voltage curve / capacity test of the entire battery).
INTERVAL U + I	Measurement of the voltage and current of a battery at any desired time interval (voltage and current curves) / capacity test of the entire battery). Example: Recording of discharge current during discharging.
DMA 35 (IrDA)	Measurement of acid density and electrolyte temperature within a block. Measurements are performed with the DMA 35 density meter (version 3) from Anton Paar GmbH.
DMA 35 (BT)	Measurement of acid density and electrolyte temperature within a block. Measurements are performed with the DMA 35 density meter (version 4) from Anton Paar GmbH.

### Measurement Inputs

Measurement Input	Function	Measurement Input	Function
S-	Input for measuring DC voltage. Measuring range: $\pm 2450.00 \text{ mV}_{\text{DC}}$ Resolution: 0.01 mV Input impedance: $>10 \text{ M}\Omega$ Sensing lead to minus pole during resistance measurement.	S+	Measurement input for direct and alternating voltage measurements. Measuring ranges: $\pm 24.5000 \text{ V}_{\text{DC}}$ Resolution: 0.1 mV $\pm 600.000 \text{ V}_{\text{DC}}$ Resolution: 1 mV $0 \dots 300.00 \text{ V}_{\text{AC}}$ Resolution: 10 mV Input impedance: $1.6 \text{ M}\Omega$ Sensing lead to plus pole during resistance measurement.
P-/COM	Reference potential (ground potential) of all measurement inputs. Current conducting cable to minus pole during resistance measurement.	P+	Current conducting cable to plus pole during resistance measurement.   <b>Attention!</b> <b>Max. 24 V<sub>DC</sub></b> Maximum test voltage must not exceed 24 V <sub>DC</sub> at input P+. The instrument is damaged if this value is exceeded.



#### Note

600 V CAT III refers to measurement inputs S+, S- and P-/COM.

# METRACELL BT PRO

## Portable Battery Tester

### Relevant Standards

The battery tester has been manufactured and tested in accordance with the following safety regulations:

IEC 61010-1 EN 61010-1 VDE 0411-1	Safety requirements for electrical equipment for measurement, control and laboratory use – General requirements
EN 60529 VDE 0470-1	Test instruments and test procedures Degrees of protection provided by enclosures (IP code)
DIN EN 61326-1 VDE 0843-20-1	Electrical equipment for measurement, control and laboratory use – EMC requirements – Part 1: General requirements

### Characteristic Values

Measuring Function	Multimeter/ Connector	Multimeter/ Float/ Discharge/ Charge	Multimeter/ Interval U / Interval U+I	Multimeter	Resistance	Temperature	
Measured Quantity	V <sub>DC</sub>	V <sub>DC</sub>	V <sub>DC</sub>	V <sub>AC</sub> <sup>1)</sup>	R <sub>el</sub> + R <sub>ct</sub>	°C	
Display Range	-2450.00 ... +2450.00 mV	-24.5000 ... +24.5000 V	-600.000 ... +600.000 V	0.00 ... 300.00 V	00.00 ... 1000.00 mΩ	-230.0... +230.0 °C <sup>2)</sup>	
Measuring Range	-2450.00 ... +2450.00 mV	-24.5000 ... +24.5000 V	-600.000 ... +600.000 V	0.00 ... 300.00 V	00.10 ... 1000.00 mΩ		
Frequency Display	-	-	-	40.00 - 99.99 Hz 100.0 - 999.9 Hz 1000 - 1400 Hz <sup>3)</sup>	-	-	
Resolution	0.01 mV	0.1 mV	1 mV	10 mV	0.01 mΩ	0.1 °C	
Input Impedance/ Test Current	>10 MΩ	1.6 MΩ	1.6 MΩ	1.6 MΩ	I <sub>p</sub> approx. 2A	>10 MΩ	
Intrinsic Uncertainty	±(0.05 % rdg. + 10d)	±(0.05 % rdg. + 10d)	±(0.05 % rdg. + 50d)	±(2.0 % rdg. + 10d) <sup>4)</sup>	±(3.0 % rdg. + 8d)		
S+	Measur- ing Con- nections	•	•	•	•		
S-		•	∞		•	•	
P+						•	
P-/ COM		•	•	• ∞	•	•	•

<sup>1)</sup> Frequency measurement only works from an input voltage of 20 V<sub>AC</sub> onwards.

<sup>2)</sup> only applicable if the temperature sensor is connected to the battery tester.

<sup>3)</sup> The frequency range of 1000 Hz to 1400 Hz is not calibrated. This is indicated in the METRACELL BT PRO display by "NC" (not calibrated).

<sup>4)</sup> within a frequency range of 45 to 500 Hz.



### Note

The characteristic values of the AC/DC current clamp sensors and the DMA 35 density meter, as well as additional characteristic values for the temperature sensor, can be found in the respective product documentation.

# METRACELL BT PRO

## Portable Battery Tester

### Technical Data

<b>Power Supply</b>	Rechargeable NiMH battery, 4 × 1,2 V type AA, round cells (recommended: Ansmann maxE 2500 mAh)	
<b>Input Impedance</b>	Measuring input S+:	1.6 MΩ
	Measuring input S-:	>10 MΩ
<b>Ambient Conditions</b>	Operating temperatures:	+5 ... +40 °C
	Storage temperatures:	-20 ... +60 °C
	Relative humidity:	max. 75 %, no condensation allowed
	Elevation:	max. 2000 m
<b>Elektrical Safety</b>	Measuring category:	600 V CAT III
	Pollution degree:	2
	Protection class:	II
	Fuse link:	1 × SIBA 600 V/10 A FF
	Test voltage:	Test voltage at measuring connection P+ may not exceed 24 VDC.
<b>Electromagnetic Compatibility (EMC)</b>	Interference emission:	EN 61326-1 class A
	Interference immunity:	EN 61326-1 EN 61326-2-1
<b>Mechanical Design</b>	Protection:	Housing IP40 per DIN VDE 0470-1/EN 60529 (protection against foreign object ingress: ≥ 1.0 mm Ø; protection against water ingress : not protected)
	Housing (W × H × D):	approx. 9.6 × 15.4 × 3.3 cm
	Weight:	approx. 0.45 kg (without rubber holster)
	Display:	LCD, monochrome, luminous
<b>Data Interfaces</b>	IrDA:	Connection for DMA 35 Basic density meter (version 3)
	RFID:	Connection for RFID tag Frequency range: 125 kHz Transmission intensity: 34.3 dBμV/m or -17.2 dBμA/m, respectively
	Wireless interface:	Connection for PC, headset and DMA 35 density meter (version 4) Frequency range: 2.4 - 2.4835 GHz Transmission intensity: max. + 3 dBm
<b>Internal Memory</b>	up to 300,000 data records	

# METRACELL BT PRO

## Portable Battery Tester

### Scope of Delivery

- 1 METRACELL BT PRO
- 4 1.2 V round cells
- 1 Power pack
- 1 Rubber holster
- 1 Carrying strap
- 1 Carrying case
- 2 Alligator clips (KY95-3)
- 1 Set of multimeter test probes (Z229B)
- 1 Set of Kelvin probes for 4-wire measurement (Z227D)
- 1 BT PRO Manager (Battery tester management software)
- 1 Test report/factory calibration certificate
- 1 Condensed operating instructions

### Optional Accessories

- AC/DC current clamp sensor
  - CP1800 (Z204A) for measurements up to 1250 A<sub>DC</sub> or
  - CP330 (Z202B) for measurements up to 300 A<sub>DC</sub>
- Temperature sensor METRATHERM IR BASE (Z680A)
- Angled probes for 4-wire measurement (Z227W)
- Spring-loaded contact pins as replacement parts (Z227F) for the Kelvin probes (Z227D) and angled probes (Z227W)



Figure 2: Battery tester with AC/DC current clamp sensor CP1800 (Z204A)



Figure 3: Battery tester with temperature sensor METRATHERM IR BASE (Z680A)



Figure 4: Kelvin probes with spring-loaded contact pins



Figure 5: Angled probes for 4-wire measurement (Z227W)

# METRACELL BT PRO

## Portable Battery Tester


### Order Information

Description	Type	Article number
Portable, multi-functional device for the testing of batteries and battery blocks; including rechargeable batteries and power pack, alligator clips, set of multimeter test probes, Kelvin probes, software and transport accessories	METRACELL BT PRO	B100B
AC/DC current clamp sensor	CP1800	Z204A
	CP330	Z202B
Temperature sensor	METRATHERM IR BASE	Z680A
Angled probes for 4-wire measurement		Z227W
Spring-loaded contact pins as replacement parts for the Kelvin probes (Z227D) and angled probes (Z227W)		Z227F

© Gossen Metrawatt GmbH

Edited in Germany • Subject to change without notice / Errors excepted • A pdf version is available on the Internet

All trademarks, registered trademarks, logos, product names, and company names are property of their respective owners.

 **GOSSEN METRAWATT**  
Gossen Metrawatt GmbH  
Südwestpark 15  
90449 Nürnberg • Germany

Phone +49 911 8602-0  
Fax +49 911 8602-669  
E-Mail [info@gossenmetrawatt.com](mailto:info@gossenmetrawatt.com)  
[www.gossenmetrawatt.com](http://www.gossenmetrawatt.com)



# Les services d'EURO-INDEX

EURO-INDEX fournit des services pour tous les instruments de sa gamme de fournitures et offre des services, de la connaissance et du personnel hautement qualifié pour l'entretien (préventif), la réparation et le calibrage de vos instruments de mesure.

## Centre de Service Agréé.....

EURO-INDEX est un Centre de Service Agréé pour toutes les marques représentées.

Autrement dit, vos instruments sont traités par du personnel formé et compétent, qui dispose des outils et logiciels adéquats. Seules des pièces d'origine sont utilisées et la garantie de votre instrument ainsi que la certification (ATEX, EN50379, etc.) restent valables.

## Laboratoire de maintenance et de calibrage .....

EURO-INDEX dispose d'un laboratoire de maintenance et de calibrage particulièrement moderne, titulaire d'une accréditation conforme à la norme NEN-EN-ISO/IEC 17025. Cette accréditation est valable pour différentes grandeurs, telles que spécifiées dans le champ d'application associé au numéro d'accréditation K105.



## MQS® .....

MQS est une formule d'entretien exclusive comportant un entretien et un calibrage périodiques de vos instruments de mesure. La prise en charge de multiples aspects vise à vous libérer de tout souci lors de l'utilisation de vos instruments de mesure. Les coûts sont modiques et prévisibles.

## Accès numérique à vos certificats de calibrage avec Mon MQS .....

Mon MQS est un portail Web qui vous donne accès partout et à tout moment à vos certificats de calibrage et aux documents apparentés.

## Location d'instruments de mesure .....

- Vaste assortiment
- Conseils avisés
- Les instruments sont livrés avec leurs accessoires et leurs certificats de calibrage traçables

## EURO-INDEX Academy .....

- Formations sur les produits (individuelles et collectives)
- Séminaires
- Vidéos de démonstration et d'instruction

**Visionnez la vidéo sur notre chaîne YouTube et découvrez tout ce qu'il vous faut savoir sur MQS**



Guichet des services



Calibrage de l'analyse de gaz de combustion



Séminaires et ateliers



Calibrage de la thermographie

Sous réserve de modifications EURO-INDEX® FR 18001

Le nom et la marque Bluetooth® sont la propriété de Bluetooth SIG Inc. L'utilisation de ce nom par EURO-INDEX s'effectue sous licence.



**BELGIQUE**  
Leuvensesteenweg 607  
1930 Zaventem  
T: 02 - 757 92 44  
F: 02 - 757 92 64  
info@euro-index.be  
www.euro-index.be

**PAYS-BAS**  
Rivium 2e straat 12  
2909 LG Capelle a/d IJssel  
T: +31 - (0)10 - 2 888 000  
F: +31 - (0)10 - 2 888 010  
verkoop@euro-index.nl  
www.euro-index.nl

