# **PS DUO** PORTABLE DUAL GAS DETECTOR

# **USER MANUAL**





www.TeledyneGFD.com



# **CONTENTS**

<ol> <li>Product Introduction</li> <li>Product Features</li> <li>Product Specifications</li> </ol>	
1.3. Product Specifications	5
	5
1.4. Gas Types	6
2. Components	7
2.1. External Components	7
2.2. LCD Display Symbols	7
2.3. Interface	8
2.3.1. Visual Display	8
2.3.2. Display Icons	8
2.3.3. One-Button Operation	8
3. Basic Operation	8
3.1. System Activation	8
3.2. System Shutdown	9
3.3. Configuration Mode	10
3.4. Peak Value	12
3.5. Alarm Display	12
3.6. Alarm Event Recording	13
3.7. Log	13
4. Calibration	10
4.1. Standard gas concentration for Calibration	11
4.2. Zero Calibration	
4.3. Span Calibration	
4.4. Judgement for Implementing	12
5. Alarm / Test Failure	13
5.1. Alarm Function	
5.2. Alarm Setting Values	14
5.3. Alarm Sound, Vibration, LED, and Display (Per Second)	
6. Certification	14
6.1. Explosion-Proof Certification	
6.2. Manufacturing Approval Error! Bookmark not def	
7. Protection Rating	14
8. Warranty and Repair	15
8.1. Sensor Replacement	
8.2. Warranty	15



# SAFETY WARNING

Before using the device, ensure that you fully understand this manual. The device must be used and repaired according to the instructions provided. Failure to follow these instructions may result in device malfunction, injury, or even life-threatening situations.



#### WARNING

- Do not replace or modify components. Doing so may void the warranty and compromise safety, even if the device is under warranty.
- Do not open or replace the battery in explosive environments. The battery should only be replaced in a safe location.
- > Ensure that there is no foreign matter on the surface of the sensors, LEDs, or buzzer before use.
- > Regularly test the gas sensor's performance using gases that exceed the alarm levels.
- Regularly test the LED, alarm, and vibration functions to ensure they are functioning properly.
- Use the device within the specified temperature, humidity, and pressure ranges. Using the device outside of these conditions may lead to malfunction or failure.
- The sensor inside the device may display different gas concentrations depending on environmental factors such as temperature, pressure, and humidity. Always calibrate the detector in environments that are similar to or match the specifications.
- Rapid changes in temperature may cause rapid changes in gas concentration. (For example, when using the detector in areas with significant temperature differences between indoors and outdoors.) Use the device once the concentration has stabilized.
- Severe pressure or impact may cause rapid changes in gas concentration. Therefore, use the device when the concentration is stable. Severe pressure or impact may also cause the sensor or device to malfunction.
- > Alarms are set according to international standards and should be adjusted by authorized professionals.
- Battery replacement should be carried out in a safe area where there is no risk of explosion or fire. Using improper replacement parts not approved by the manufacturer may void the warranty.
- Wireless communication should be carried out in a safe area where there is no risk of explosion or fire.
- Do not expose the detector to poisons such as alcohol or citrus-based products. Poisons can compromise the accuracy and response time of the device.
- > If sensor contamination is suspected, confirm using calibration, bump tests, etc.
- This detector is designed to be used in explosive atmospheres where oxygen levels do not exceed 20.9% (v/v). Some sensor outputs may be suppressed in oxygen-deficient environments (<10% v/v).</p>
- Do not charge primary cell batteries. Replace the battery at a Teledyne GMI authorized service center before it is fully discharged.
- > Do not calibrate the device when it has been exposed to conditions representing the IP rating.
- > Use dedicated calibration caps or calibration equipment for calibration.
- > Do not perform calibration during the device's stabilization process after power-up.
- Sudden changes in atmospheric pressure may temporarily destabilize oxygen concentrations.
- Check for obstructions, debris, or blockages in the gas inlet every day before use. If the gas inlet is blocked by contaminants, the actual detected concentration may be measured lower than the normal level.
- > The device should be carried at all times and not left unattended.
- If there is a mechanism that generates charges, the exposed metal parts of the enclosure may store electrostatic charges at levels that could be ignitable for IIC gases. Therefore, users/installers should take



the aforementioned precautions to prevent static accumulation. This is particularly important when bringing the equipment into Zone 0 locations.

The battery and sensor should be replaced by a Teledyne GMI authorized service center in a safe area where there are no hazardous gases.



#### Caution

- > Please read the manual carefully before use.
- > This device is a gas detector, not a measurement instrument.
- > If continuous calibration failures occur, discontinue use and contact the manufacturer.
- > Test the device every 30 days in a clean air environment free of gases.
- > Clean the exterior of the product with a soft cloth; do not use chemical solvents.



#### Special Conditions for Safe Use

- Do not open or replace the battery in explosive environments. The battery should only be replaced in a safe location.
- Only use SB-AA02(P) (Vitzrocell) batteries.
- Do not use the device in environments with temperatures, humidity, or pressure outside the specified ranges.
- Ensure that there are no foreign substances on the sensor, LED, or buzzer before use.
- > For consistent performance, periodically test the device with gases that exceed the alarm thresholds.
- If it is found that the film does not comply with inspection conditions, it must be reapplied according to the manufacturer's instructions. Ensure it is not exposed to excessive heat, harsh chemicals or solvents, sharp edges, or abrasive surfaces.



# **1. Product Overview**

#### **1.1. Product Introduction**

The PS DUO is a portable diffusion-type gas detector that alerts users to hazardous environments related to gases. The detector displays the concentration of oxygen or toxic gases on an LCD monitor. It is easy and simple to operate, and alerts the operator of danger through an alarm, LED, and vibration if the gas concentration exceeds the safe limit. This device displays real-time gas concentrations and identifies maximum and minimum levels. Settings can be adjusted wirelessly.



#### **1.2. Product Features**

- Equipped with a miniaturized electrochemical gas sensor
- Wireless communication functionality
- Excellent waterproof and dustproof construction
- Replaceable battery design
- Power On/Off capability

#### **1.3. Product Specifications**

Model Name	PS DUO		
Sensor Type	Electrochemical		
Measurement Type	Diffusion Type		
Case	TPU + Polycarbonate (PC)		
Size	56(W) x 89(H) x 21(D)mm		
Weight	200g		
Operating Temperature	-20°C ~ +50°C		
Operating Humidity	15% ~ 90% RH(Non-condensing)		
Environmental Conditions	Pollution Degree: "2", Atmospheric Pressure: 80 ~ 120KPa		
Operation	A clip is attached to the device, allowing it to be easily carried by the user on a pocket, belt, helmet, etc.		
Alarm	Visual (LED), Tactile (Vibration), Audible (95dB) alarms		
Display	Liquid Crystal Display (LCD)		
Battery	Lithium Primary Battery (Li/SOCl2), Nominal Voltage: 3.6V, Nominal Capacity: 1,200mAh		
Rating	Powered by 3.6VDC battery		
Battery Life	Approximately 2 years (8 hours of daily use, wireless off) X Battery life may vary depending on usage conditions and environment.		
Calibration Interval	The detector can be calibrated in an appropriate environment as needed.		
Accessories	Calibration cap		



#### 1.4. Gas Types

The detector can monitor various types of gases, including oxygen and toxic gases and it is available in the following configurations:

Model Na	ame	Gas	Гуре		
Model	х	Ch-A	Ch-B		
	3				СО
	4		H2S		
	5		SO2		
	6	02	H2		
	7	-	NO2		
	8		NH3		
PS DUO	9		03		
	А		СО		
	В	NO2	H2S		
	С		SO2		
	D		H2S		
	E	SO2	СО		
	F	NH3	СО		



# 2. Components

#### 2.1. External Components



### 2.2. LCD Display Symbols

LO	- Low Alarm - 1 <sup>sτ</sup> Warning	Ō	- Battery or Calibration Date Check - Countdown
HI	- High Alarm - 2 <sup>nd</sup> Warning	$\checkmark$	<ul> <li>Calibration Success</li> <li>Software Version Check</li> <li>Device Settings</li> </ul>
	- Alarm Level Exceeded Indicator	\$	- Zero Calibration (Fresh Air Calibration)
STEL	- STEL Alarm		- Span Calibration (Standard Gas Concentration Calibration)
TWA	- TWA Alarm		- Sufficient Battery Remaining
ጮ	- Wireless Indicator		- Low Battery



# **PS DUO USER MANUAL**

#### 2.3. Interface

#### 2.3.1. Visual Display

The detector features an LCD (Liquid Crystal Display) that shows the following:

- Gas type monitoring
- Alarm levels triggered: low or high (including ppm or %vol concentration levels)
- Alarm settings: low and high Peak (maximum) alarm exposure

#### 2.3.2. Display Icons

The LCD of the detector also includes icons that clearly indicate:

- Alarm type and alarm level
- Diagnostic warnings

#### 2.3.3. One-Button Operation

- Activate the detector
- Display alarm set points
- Display maximum gas exposure
- Display remaining days for bump test
- Display remaining days for calibration
- Display firmware version
- Display calibration gas concentration
- Display all LCD icons
- Set up the detector
- Deactivate the detector

# 3. Basic Operation

#### 3.1. System Activation

The detector features a single user interface button for implementing functions such as device activation.

- Before use, check the activation deadline, and do not activate the product if the deadline has passed.
- 2 Move to a safe environment.
- ③ Press and hold the button until the 3-second countdown is displayed.
- (4) The device will then power on, turning on all LCD segments with a short vibration.
- 5 The detector will operate in measurement mode.



Process of system On and Boot



#### 3.2. System Shutdown

In measurement mode, pressing and holding the button for 3 seconds will display a system shutdown countdown on the LCD.



#### Process of system Off



#### **3.3. Configuration Mode**

In measurement mode, press the button briefly to switch modes. The device features several modes, as shown in the illustration below. Each mode is distinguished by the active icon displayed on the top screen.



#### 3.4. Calibration

For calibration on the device, move the clean atmosphere. And then, perform the zero calibration and span calibration. Ensure to use the exclusive calibration cap or device for calibration. Note that calibration cap must be equipped toward upward arrow pointing.



#### 3.5. Standard gas concentration for Calibration

Be use the standard gas and concentration for each sensor when it's calibrating. Standard gas concentration can be changed using IR Connect program.

Con Senser huma		Measurement Info.				Cal. Standard	
Gas	Sensor type	Range		Resolution		Concentration	
Oxygen	Electrochemical	0 to 30	%vol	0.1	%vol	18	%vol
Carbon monoxide	Electrochemical	0 to 500	ppm	1	ppm	100	ppm
Hydrogen sulfide	Electrochemical	0 to 100	ppm	0.1	ppm	25	ppm
Sulfur dioxide	Electrochemical	0 to 20	ppm	0.1	ppm	5	ppm
Hydrogen	Electrochemical	0 to 1000	ppm	1	ppm	500	ppm
Nitrogen dioxide	Electrochemical	0 to 20	ppm	0.1	ppm	10	ppm
Ammonia	Electrochemical	0 to 100	ppm	1	ppm	50	ppm
Ozone	Electrochemical	0 to 20	ppm	0.1	ppm	16 (Using I	ppm NO2 20 ppm)

#### 3.6. Zero Calibration

Zero calibration means fresh air correction. On the Calibration mode, Press and hold the button for 2 seconds to enter the sub menu. Press and hold the button when the zero-calibration icon is on the display. Select the channel which is implemented zero calibration. And then, Press and hold the button for 2 seconds to calibrating.





#### 3.7. Span Calibration

Span calibration means standard gas concentration correction. On the Calibration mode, Press and hold the button for 2 seconds to enter the sub menu. Press and hold the button when the span-calibration icon is on the display. Select the channel which is implemented span calibration. And then, Press and hold the button for 2 seconds to calibrating.



#### 3.8. Judgement for Implementing

Result for calibrating is on the display for each gas channel after implementing.







When gas is detected, the detector records the maximum exposure concentration. The recorded value can be cleared.

#### 3.10. Alarm Display

3.9. Peak (Max) Value

The detector monitors gas concentrations and displays the alarm status when the gas concentration exceeds the alarm set point.



#### **3.11.** Acquiring Alarm Events

Data stored in the detector's memory can be downloaded via IrDA. The stored information includes calibration events, LOW and HIGH alarms (including time of occurrence, duration, and gas concentration).

#### 3.12. Log

During operation, data, event, calibration, and bump test logs are stored. The stored data can be downloaded using IR Connect and a PC program.

Category	Details	
<b>Event Alarms</b>	Time of occurrence, duration, alarm type, gas concentration, serial	
(High, Low, TWA, STEL)	number	
Bump Test Logs	Test date, success/failure, calibration gas concentration, detected concentration	
Calibration Logs Calibration date, type, calibration gas concentration, det		
Data Logs	Date and time of IR Connect execution, concentration, alarm type, options	

# 4. Alarm / Test Failure

#### 4.1. Alarm Function

When the gas concentration exceeds the alarm set value, the alarm status is displayed on the LCD, and the device vibrates, flashes (LED), and emits a beep. To stop the alarm, move to an area with clean air, and the alarm will automatically stop.

Category	Details		
Gas Alarm	The alarm set values are pre-programmed (primary, secondary alarms) at the factory. If the detector is exposed to concentrations above the upper limit, an OL (Over Limit) alarm is displayed on the LCD.		
Visual Alarm	The LCD and three flashing LED areas will indicate when the gas concentration exceeds the alarm set value (primary, secondary alarms).		
Audible Alarm	The programmed audible alarm is triggered when the gas concentration exceeds the alarm set value (primary, secondary alarms), and it emits a beep as a warning.		
Vibration AlarmThe vibration motor activates when the gas concentrationVibration Alarmthe alarm set value (primary, secondary alarms), providi warnings even in noisy areas.			



#### 4.2. Alarm Setting Values

The default alarm set values are configured at the factory. Alarm set values can be adjusted either on the device itself or using the IR Connect. All alarm values are preset according to alarm standards required by international standards. Therefore, alarm values can only be changed under the responsibility and approval of the site manager where the device is used.

#### 4.3. Alarm Sound, Vibration, LED, and Display (Per Second)

Category	Details	
Low Alarm	The Low icon on the top screen is illuminated.	
High Alarm	The High icon on the top screen is illuminated.	
TWA Alarm	The TWA icon on the top screen is illuminated.	
STEL Alarm	The STEL icon on the top screen is illuminated.	

## 5. Certification

#### 5.1. Explosion-Proof Certification

The detector is certified according to the following standards:

Certification			
IECEx	IECEx KSCP 25.0001X	Ex ia IIC T4 Ga	
	KSCP 25ATEX0001X	II 1 G Ex ia IIC T4 Ga	

## 6. Protection Rating

The detector's IP Rating should be assessed as IP67. The product complies with Directive 2014/30/EC (EMC).



# 7. Warranty and Repair

#### Warning

- Never replace the battery in explosive or hazardous areas.
- Replace the battery in a clean environment free of hazardous gases, as failure to do so may lead to severe accidents (serious injury or fatality).
- Replacing parts may invalidate the intrinsic safety features.
- Sensor and battery replacement should be performed by authorized dealers, distributors, or managers.
- Only sensors designated by Teledyne GMI should be used for replacement.
- Disassembly is only necessary for sensor and battery replacement. After sensor replacement, a Span gas calibration must be performed.
- Before disassembly, ensure the power is turned off and remove the screws.

#### 7.1. Sensor Replacement

- 1. Deactivate the detector.
- 2. Remove the six screws from the rear cover.
- 3. Remove the two screws securing the PCB.
- 4. Flip the PCB over, remove the old sensor, and replace it with a new sensor.
- 5. Reassemble the PCB and rear cover.
- 6. After reassembly, perform Zero calibration and Span calibration according to the standards in this manual.

#### 7.2. Warranty

The warranty period is 2 years from the date of purchase from the manufacturer or an authorized reseller.

The manufacturer is not responsible for defects if, upon testing and inspection, the product is found to be free of defects or if the defect was caused by misuse, neglect, improper installation, testing, or calibration by the purchaser (or a third party). Unauthorized attempts to repair or modify the product, or damage caused by fire, lightning, water, or other hazards, are also excluded from the manufacturer's responsibility.

If the product fails to meet the manufacturer's specifications during the warranty period, please contact the authorized reseller or Teledyne GMI service center for repair/return information.





www.TeledyneGFD.com



AMERICAS 14880 Skinner Road Cypress, TX 77249, USA Tel: +1-713-559-9200 EMEA Inchinnan Business Park Renfrew, PA4, 9RG Scotland, UK Tel.: +44 (0) 141 812 3211 ASIA PACIFIC 290 Guigiao Road Pudang, Shanghai 201206 People's Republic of China Tel.: +86-21-3127-6373