

Multifunctional installation testers

MI 3125BT EurotestCOMBO



The MI 3125BT EurotestCOMBO performs all the necessary tests for installation safety testing on TT and TN systems. The large graphic display with backlight offers easy reading of results, indications, measurement parameters and messages. Two LED Pass/Fail indicators are placed on both sides of the LCD. MI 3125BT EurotestCOMBO contains integrated characteristics of fuses and RCDs (including B type) for the evaluation of test results. Each test has its own individual help screen describing how to connect the instrument into the installation and how to perform a measurement. All the results can be quickly saved and referenced on the instrument and then downloaded via the EuroLink PRO software, included in the standard set, to the computer for evaluation and report generation after testing. MI 3125BT EurotestCOMBO performs continuity, insulation, RCD, loop, line, voltage, frequency, earth resistance testing and phase sequence tests required by the EN 61557 standard.

MEASURING FUNCTIONS

- Insulation resistance with DC voltage;
- Continuity of PE conductors with 200 mA test current with polarity change;
- Continuity of PE conductors with 7 mA test current (continuous measurement) without RCD tripping;
- Line impedance;
- Loop impedance;
- Loop impedance with Trip Lock RCD function;
- TRMS voltage and frequency;
- Phase sequence;
- RCD testing (general and selective, type AC, A, F, B, B+ and EV RCD);
- Earth resistance (3-wire method).

KEY FEATURES

- **LED Pass/Fail indicators:** two LED indicators for PASS / FAIL evaluation of test results are placed on both sides of the LCD
- **Help screens:** instrument comes complete with built-in help screens for referencing on site.
- **Earth resistance measurement:** instrument performs 3-wire earth resistance testing with two additional rods.
- **Built-in fuse tables:** this unique feature allows automatic evaluation of the line / loop impedance compared to the regulations.
- **Online voltage monitoring:** monitors all 3

voltages in real-time.

- **Upgradeable:** if changes occur to the regulations, upgrades can be made to the firmware to keep the instrument up to date.
- **Polarity swap:** automatic polarity reversal on continuity test.
- **Insulation range:** wide range of insulation test voltages from 50 V to 1000 V, reading up to 1000 M Ω .
- **Trip Lock function:** Zs (RCD) function performs a loop impedance test without tripping the (EV) RCD.
- **Multi-system testing:** tests on single and multiphase TT and TN systems.
- **Built-in charger & rechargeable batteries:** unit has a built-in charging circuit and comes complete with a set of rechargeable NiMH batteries.
- **RCD auto:** automated RCD testing procedure significantly reduces test time.
- **B type RCD and EV RCD testing** are supported. .
- **BT connectivity:** it enables BT communication with Android tablets and smart phones via built-in BT.
- **PC SW EuroLink PRO** included in the standard set enables downloading of test results and parameters and creation of test reports.
- **Compatible with PC SW MESM** (Metrel ES Manager).

APPLICATION

- Initial and periodic testing of domestic and industrial installations;
- Testing of single and multiphase systems;
- Testing of TT and TN systems.

STANDARDS

Functionality:

- IEC/EN 61557

Other reference standards for testing:

- VDE 0413;
- IEC/EN 61008;
- IEC/EN 61009;
- IEC/EN/HD 60364;
- HD 384; BS 7671;
- IEC/TR 60755;
- CEI 64.8;
- AS/NZ 3760;
- AS/NZ 3018

Electromagnetic compatibility:

- IEC/EN 61326-1;
- IEC/EN 61326-2-2

Safety:

- IEC/EN 61010-1;
- IEC/EN 61010-031

TECHNICAL DATA

| FUNCTION | Measuring range | Resolution | Accuracy |
|---|---|------------|--------------------------------------|
| Insulation resistance (EN 61557-2) | U = 50, 100, 250 VDC: | | |
| | R: 0.00 MΩ ... 19.99 MΩ | 0.01 MΩ | ±(5 % of reading + 3 digits) |
| | 20.0 MΩ ... 99.9 MΩ | 0.1 MΩ | ±10 % of reading |
| | 100.0 MΩ ... 199.9 MΩ | 0.1 MΩ | ±20 % of reading |
| | U = 500 VDC, 1 kVDC: | | |
| | R: 0.00 MΩ ... 19.99 MΩ | 0.01 MΩ | ±(5 % of reading + 3 digits) |
| Continuity 200 mA of PE conductor with polarity change (EN 61557-4) | 0.00 Ω ... 19.99 Ω | 0.01 Ω | ±(3 % of reading + 3 digits) |
| | 20.0 Ω ... 199.9 Ω | 0.1 Ω | ±5 % of reading |
| | 200 Ω ... 1999 Ω | 1 Ω | ±5 % of reading |
| | 0.0 Ω ... 19.9 Ω | 0.1 Ω | ±(5 % of reading + 3 digits) |
| | 20 Ω ... 1999 Ω | 1 Ω | ±(5 % of reading + 3 digits) |
| | 1.00 kΩ ... 9.99 kΩ | 10 Ω | ±10 % of reading |
| Line impedance (EN 61557-3) | 0.00 Ω ... 9.99 Ω | 0.01 Ω | ±(5 % of reading + 5 digits) |
| | 10.0 Ω ... 99.9 Ω | 0.1 Ω | ±(5 % of reading + 5 digits) |
| | 100 Ω ... 999 Ω | 1 Ω | ±10 % of reading |
| | 1.00 kΩ ... 9.99 kΩ | 10 Ω | ±10 % of reading |
| Voltage drop | 0.0 % ... 99.9 % | 0.1 % | Consider accuracy of line impedance |
| | 0 V ... 550 V | 1 V | ±(2 % of reading + 2 digits) |
| Frequency | 0.00 Hz ... 9.99 Hz | 0.01 Hz | ±(0.2 % of reading + 1 digits) |
| | 10.0 Hz ... 499.9 Hz | 0.1 Hz | |
| Phase sequence (EN 61557-7) | 1.2.3 or 3.2.1 | | |
| RCD testing (EN 61557-6) | IΔN: 10 mA, 30 mA, 100 mA, 300 mA, 500 mA, 1 A | | |
| - Contact voltage UC | 0.0 V ... 19.9 V | 0.1 V | (-0 % / +15 %) of reading ±10 digits |
| | 20.0 V ... 99.9 V | 0.1 V | (-0 % / +15 %) of reading |
| - Trip-out time | 0 ms ... 40.0 ms | 0.1 ms | ±1 ms |
| | 0 ms ... max. time | 0.1 ms | ±3 ms |
| - Trip-out current | 0.2 x IΔN ... 1.1 x IΔN (AC type) | 0.05 x IΔN | ±0.1 x IΔN |
| | 0.2 x IΔN ... 2.2 x IΔN (A, F types, IΔN < 30 mA) | 0.05 x IΔN | ±0.1 x IΔN |
| | 0.2 x IΔN ... 1.5 x IΔN (A, F types, IΔN ≥ 30 mA) | 0.05 x IΔN | ±0.1 x IΔN |
| | 0.2 x IΔN ... 2.2 x IΔN (B, B+ types) | 0.05 x IΔN | ±0.1 x IΔN |
| | 0.2 x IΔN ... 1.0 x IΔN (EV RCD a.c. part) | 0.05 x IΔN | ±0.1 x IΔN |
| | 0.2 x IΔN ... 1.0 x IΔN (EV RCD d.c. part) | 0.05 x IΔN | ±0.1 x IΔN |
| Earth resistance (EN 61557-5) | 0.00 Ω ... 19.99 Ω | 0.01 Ω | ±(5 % of reading + 5 digits) |
| | 20.0 Ω ... 199.9 Ω | 0.1 Ω | ±(5 % of reading + 5 digits) |
| | 200 Ω ... 9999 Ω | 1 Ω | ±(5 % of reading + 5 digits) |
| Power supply | 6 x 1.2 V rechargeable batteries, type AA | | |
| Overvoltage category | CAT III / 600 V; CAT IV / 300 V | | |
| Protection class | Double insulation | | |
| COM port | RS232 and USB | | |
| Dimensions | 140 x 80 x 230 mm | | |
| Weight | 1.0 kg | | |

METREL d.d.
 Measuring and Regulation Equipment Manufacturer
 Ljubljanska 77, SI-1354 Horjul, Slovenia
 T +386 (0)1 75 58 200, F +386 (0)1 75 49 226
 info@metrel.si, www.metrel.si

ORDERING INFORMATION



Standard set (MI 3125BT)

- Instrument EurotestCOMBO
- Set of carrying straps
- Test lead, 3 x 1.5 m
- Schuko-plug test cable, 1.5 m
- Test probe, 3 pcs (blue, black, green)
- Crocodile clip, 3 pcs (blue, black, green)
- Power supply adapter + 6 NiMH rechargeable batteries, type AA
- USB and RS232 - PS/2 cable
- PC SW EuroLink PRO
- Short instruction manual
- Instruction manual and handbook on storage media
- Calibration certificate

OPTIONAL ACCESSORIES

| Photo | Part No. | Description |
|-------|------------|--|
| | A 1110 | Three phase adapter |
| | A 1111 | Three phase adapter with switch |
| | A 1153 | Test lead, black, 20 m |
| | A 1154 | Test lead, black, 4 m |
| | A 1314 | Plug commander |
| | A 1401 | Tip commander |
| | A 1303 | Soft hand strap |
| | A 1289 | Soft carrying bag |
| | A 1271 | Small soft carrying bag |
| | A 1292 | Upgrade code EuroLink PRO to EuroLink PRO Plus |
| | A 1431 | EuroLink Android APP |
| | P 1102 AND | Metrel aMESM PRO License Key Upgrade (A 1522) |
| | P 1101 | Metrel MESM BASIC to PRO licence key Upgrade |
| | S 2026 | Earth test set, 3-wire, 20 m |
| | S 2027 | Earth test set, 3-wire, 50 m |

Note! Photographs in this catalogue may slightly differ from the instruments at the time of delivery. Subject to technical change without notice.

Services d'EURO-INDEX

EURO-INDEX est un fabricant, importateur et distributeur de diverses marques A dans le domaine des instruments de test et de mesure. Nous fournissons également une large gamme de services pour optimiser l'utilisation de ces instruments dans vos activités. Ces services comprennent naturellement l'entretien, la réparation et l'étalonnage des instruments, mais nous proposons aussi une assistance sous forme de formation via notre EURO-INDEX Academy et la location d'instruments.

Centre de Service Agréé

EURO-INDEX est un Centre de Service Agréé pour toutes les marques représentées. Cela signifie que vos instruments sont pris en charge par des techniciens formés par le fabricant et disposant des outils et logiciels adéquats. Seules des pièces d'origine sont utilisées et la garantie de votre instrument, ainsi que les certifications (ATEX, EN50379, etc.) restent intactes.

Laboratoire de maintenance et de calibrage

Le laboratoire des Pays-Bas est accrédité RvA selon la norme EN-ISO/IEC 17025. Cette accréditation est valable pour différentes grandeurs, telles que spécifiées dans le champ d'application associé au numéro d'accréditation K105. Les certificats de calibrage RvA sont acceptés à l'international et équivalents à ceux de BELAC.



Service Mobile

Outre les laboratoires d'étalonnage fixes de Zaventem et de Capelle aan den IJssel, nous disposons également d'un laboratoire itinérant appelé "Service mobile". Nos services peuvent venir vers vous, en offrant une qualité équivalente.

MQS®

MQS® est une formule d'entretien exclusive comportant un entretien et un calibrage périodiques de vos instruments de mesure à un coût fixe et faible. Via un portail Web gratuit (monmq.be), vous avez toujours accès à vos certificats de calibrage.

Location d'instruments de mesure

- Vaste assortiment
- Précision démontrable par le certificat d'étalonnage actuel
- Conseils avisés
- Les instruments sont livrés avec leurs accessoires

EURO-INDEX Academy

- Formations et séminaires
- Vidéos de démonstration et d'instruction
- Notes d'application



Comptoir de service



Entretien, réparation et calibrage



Formations et séminaires



Service Mobile

Sous réserve de modifications EURO-INDEX® FR 23001



BELGIQUE
Chaussée de Louvain 607
1930 Zaventem
T: 02 - 757 92 44
F: 02 - 757 92 64
sales@euro-index.be
www.euro-index.be

PAYS-BAS
Rivium 2e straat 12
2909 LG Capelle a/d IJssel
T: +31 - (0)10 - 2 888 000
F: +31 - (0)10 - 2 888 010
verkoop@euro-index.nl
www.euro-index.nl

